



ID 1 motor ~ ID 8 motor

AX-12A x8




ID 9 motor ~ ID 18 motor

AX-18A x10



CM-530



BATTERY



DMS



GYRO



LED BOARD



CABLE-BAT




F7 x2



F54 x4



F55 x20



F60 x1




BU x20



WA x30



PLATE 3x7



RC-100A



PIN HOLE x6



PIN x6



FR04-HC110 x2



FR04-H120 x2



FR04-H101 x2



FR04-SC110 x2



FR04-E160 x2



FR04-E175 x1



FR04-E191 x1



FR04-E120 x1



FR04-E131 x1



FR04-E150 x1



PR10-SPACER-01 x1



FR04-X101 x2



FR04-H102 x4



FR04-SC101 x2



FR04-E180 x2









FR04-E170 x2



FR04-E171 x2



FR04-S101 x2

-  WB M2x03 x100
-  WB M2x06 x200
-  WB M2x08 x 6
-  WB M2.5x04 x20
-  WB M3x10 x10
-  WB M3x12 x20

-  SP1 x10
-  N1 x150
-  N2 x10
-  S2 x10
-  S3 x 5



RIVET BOX



LOCTITE



CHARGER



CABLE-10 x6



SMPS



MINI USB CABLE



CABLE-14 x6



5P-CABLE-15 x1



CABLE-DMS x3



CABLE-18 x4



FUSE



CD



Quick Start



DRIVER